# **Active Directory Intial Setup**

# WE Innovate X Zero\$ploit

Supervised By : Zeyad Mazen Prepared By : Omar Hassan

# **Active Directory Setup**

In this scenario, we are tasked with setting up and configuring Active Directory (AD) in a Windows Server environment using Packet Tracer or a virtualized lab. Active Directory will allow centralized management of users, computers, and security policies, while enabling authentication and access control within the domain.

# **Topology Requirements**

- 1 Windows Server (acting as Domain Controller)
- 1 Switch
- 10 Client PCs (Windows 10/11)
- 1 Router (optional, if connecting to external networks)
- All devices should be on the same subnet for domain communication

## **Server Preparation**

Before configuring Active Directory, ensure the Windows Server machine is properly set up:

- Assign a static IP address to the server.
- Configure the hostname (e.g., DC1).
- Verify network connectivity between the server and client PCs.

#### Step 1: Install Active Directory Domain Services (AD DS)

- 1. Open \*\*Server Manager\*\*.
- 2. Click \*\*Manage > Add Roles and Features\*\*.
- 3. In the wizard, select \*\*Active Directory Domain Services (AD DS)\*\* and complete the installation.
- 4. Once installed, a notification will appear to promote the server to a domain controller.

#### **Step 2: Promote Server to Domain Controller**

- 1. In \*\*Server Manager\*\*, click the notification flag and choose \*\*Promote this server to a domain controller\*\*.
- 2. Select \*\*Add a new forest\*\* and specify a root domain name (e.g., company.local).
- 3. Set a \*\*Directory Services Restore Mode (DSRM)\*\* password.
- 4. Complete the wizard and restart the server.

#### **Step 3: DNS Configuration**

During domain controller promotion, DNS services are installed automatically. Verify DNS by ensuring:

- The domain controller has a loopback DNS entry (127.0.0.1).
- Client PCs are configured to use the domain controller's IP address as their primary DNS.

# **Step 4: Create Users and Organizational Units (OUs)**

- 1. Open \*\*Active Directory Users and Computers\*\* from Administrative Tools.
- 2. Create Organizational Units (e.g., HR, Sales, IT).
- 3. Add users inside each OU and assign them to security groups as needed.
- 4. Apply Group Policies (via Group Policy Management) for centralized control.

## **Step 5: Join Client PCs to the Domain**

On each Windows 10/11 PC:

- 1. Open \*\*System Properties\*\* (Win+Pause > Change Settings).
- 2. Click \*\*Change\*\*, select \*\*Domain\*\*, and enter the domain name (e.g., company.local).
- 3. Provide domain administrator credentials when prompted.
- 4. Restart the PC to apply changes.
- 5. Verify login using a domain account.

# **Verification & Testing**

Once setup is complete:

- Ping the domain controller from client PCs to verify connectivity.
- Log in with a domain user account on client PCs.
- Test Group Policy application (e.g., password policies, desktop restrictions).
- Verify DNS resolution within the domain.